

Fitting Instructions

For full installation instructions please visit www.vertiflor.co.id

1. Before you start

Vertiflor® 5G Click RVT can be fitted quickly and easily without adhesive. When fitting in areas subject to heavy load, or excessive heat or direct sunlight, it is recommended to have an expansion gap of at least 8mm all around the edge of the wall.

Fully acclimatise your RVT by removing the packaging and leaving it in the room where it is to be installed for 24 hours before installation. We recommend you keep the room at a constant temperature between 22 to 27C during this period.

We recommend you mix the planks when fitting from multiple packs to give a more natural appearance to your flooring.

1. Subfloors

Although Vertiflor® 5G Click RVT is water-resistant, it cannot be used as a moisture barrier. Your subfloor must be completely dry before installation.

Subfloors must be structurally sound, solid, stable, level, plumb, and true to tolerance in a plane of 6mm in 4m. Cracks and holes must be filled or leveled with a self-leveling compound or similar. Any raised patches or bumps should be sanded down. Any carpet staples, grippers, adhesive residue, etc must be removed. Bumps, voids, and other obstacles can interfere with the locking mechanism and must be fixed before installation.

Vertiflor® 5G Click RVT can be fitted over existing firm floors like Ceramic Tiles, PVC, etc, but all textile floors should be removed. When laying over concrete floors, you must first level it with a self-leveling compound or similar.

2. Measuring & Planning

When fitting any plank or tile flooring it is always recommended to start on the longest wall, with the longest edge of the plank running along the length of the room. Make sure you leave an expansion gap of at least 0.5cm around the edge of the room, especially when loose laying.

3. Fitting

Vertiflor[®] 5G Click RVT allows each tile to simply click into place, allowing for fast and simple installation. As stated above, it is highly recommended you mix tiles from each pack to achieve a more uniform appearance throughout the room.

Use of a pull bar and tapping block is recommended to ensure a successful install.

Vertiflor[®] 5G Click RVT provides a very tight fit. Proper care must be taken to ensure all seams are tight at the end of installation. An unprofessional installation or use of improper tools can result in damage to the 5G locking profiles.

4. Adhesives

Vertiflor[®] 5G Click RVT is primarily a DIY product that is fitted without adhesive. We recommend that if you seek a professional fitter to install your floors as heat, moisture, and sunlight can be deciding factors.

Do not install on concrete floors that are excessively cold or radiant-heated floors that exceed 25C. Radiant heating should be turned off 12 hours before installation.